

< Quick Start-Up Guide on Labview >

Date: 2014/11/04

As following item are required to work Sentech camera on Labview.

- Sentech USB camera Driver => Please refer [this link](#)
- Sentech USB camera NI Labview adopter => Please refer [this link](#)

1 Installing Setech USB camera Driver

- Install Sentech USB camera Driver as bellow location.
¥StCamUSBPack_EN_*****¥1_Software_Driver¥StCamSWare(v3.06)
- Select "Custom"
- Select "Driver" only, please un-check DLL, StCamSWare, Direct Show and TWAIN



- Completed install Driver

2 Select Sentech USB camera adopter

Please copy this adopter on User's PC.

Adopter

Labview 2013 or later : Driver_LabView(LV2013).zip

Older than Labview 2013 : Driver_LabView(Older).zip

Location

¥StCamUSBPack_EN_*****¥4_Other_Drivers¥LabVEIW

3 Instruction

Execute Acquire with Attributes - StTrg 1.vi

StTrg 1.vi works on Monochrome camera. This vi-file have limited functions, User can add another function through vi files as bellow location.

¥Driver_LabView(LV2013)¥Shared Library - Trigger SDK¥VIs

end